CLICK SEAL FLEXIBLE HOSE CONNECTOR INSTRUCTIONS

Before starting work:

- 1. Turn off water supply to point of installation.
- 2. Drain system where necessary.
- 3. If required, clean all existing threads on mating parts.
- 4. Some work is subject to regulations if in doubt consult your water authority or a competent plumber.
- 5. When installing the Fluidmaster Click Seal[®] connector, please ensure the product is not: Bent at sharp angles; squashed; kinked; stretched; twisted or split.

CLICK SEAL FITTING Installation instructions:


- 1. Place Click Seal nut onto end of tap or toilet valve thread.
- 2. Turn Click Seal nut clockwise and HAND-TIGHTEN until nut clicks. "The click lets you know it's sealed."®

15mm COMPRESSION FITTING Installation instructions:

15mm COPPER TUBE



FLEXIBLE HOSE



- 1. Prepare end of copper tube ensuring clean, smooth and bur-free fitting available.
- 2. Connect the compression joint by sliding the nut then the olive over the copper tube.
- 3. Position the hose and hand tighten.
- 4. Tighten compression nut first by hand, then using a suitable wrench tighten firmly. **DO NOT OVER TIGHTEN.**
- 5. Slowly turn on water supply and check there are no leaks. Tighten nut further if necessary.
- 6. If in doubt, contact a competent plumber.