



TOILET SYMPTOM:

A Clunk is Heard as the Inlet/Fill/Float Valve Shuts Off

All modern Inlet/Fill/Float Valves are equilibrium valves which are positively open or positively closed and will search out any loose pipes.

Alternatively, in order to fit the new fill valve, some of the water has been drained off and the air in the pipework has moved.

- 1) Turn off water at the main stopcock and turn on all cold taps including any outside ones also flush the toilets.
 - a) This will allow the air back into the system.
 - b) Turn on the water again then, working away from the stopcock, turn off the taps one by one, this will push the air through the pipes and should resolve the problem.
 - c) It may have to be repeated a couple of times to get the air into the right places.